## READ THIS FIRST

We have designed your telephone to conform to federal regulations and you can connect it to most telephone lines. However, each device you connect to the phone line draws power from it. This power draw is the device's *Ringer Equivalence Number*, or REN. The REN is shown on the bottom of your phone.

If you are using more than one phone or other device on the line, add up all the RENs. If the total is more than five (or three in rural areas) your phones might not ring. If ringer operation is impaired, remove one of the devices from the line.

If your phone causes problems on the phone line, the telephone company can disconnect your service. The phone company tries to notify you in advance. If advance notice is not practical, the telephone company notifies you as soon as possible and advises you of your right to file a complaint with the FCC.

The phone company can also make changes to its lines, equipment, operations, or procedures that could affect the phone's operation. The phone company notifies you in advance, so you can take the necessary steps to prevent interruption of your phone service.

## FCC STATEMENT

Your telephone complies with Part 68 of *FCC Rules*. You must, upon request, provide the FCC registration number and the REN to your telephone company. These numbers are shown on the bottom of your phone.

**Note:** You must not connect your telephone to:

- Coin-operated systems
- Party-line systems
- Most electronic key phone systems

## CARE

- Keep the phone dry.
- Handle the phone carefully. Do not drop it.
- Do not use or store the phone in temperature extremes.
- Keep the phone away from dust and dirt.
- Do not modify or tamper with the phone's internal components. Doing so might invalidate the phone's warranty and void your FCC authorization to operate it. If the phone is not operating as it should, take it to your local Radio Shack store for assistance. If the trouble is harming the phone lines, the phone company might ask you to disconnect the telephone until you fix the problem.

RADIO SHACK LIMITED WARRANTY

This telephone product is warranted against manufacturing defects in material and workmanship for one (1) year from the date of purchase from Radio Shack company owned stores and authorized Radio Shack franchisees and dealers. Within this period **bring your Radio Shack sales slip** as proof-of-purchase date to any Radio Shack store.

This warranty does not cover damage or failure caused by or attributable to Acts of God, abuse, misuse, improper or abnormal usage, faulty installation, improper maintenance, lightning or other incidence of excess voltage, or any repairs other than those provided by a Radio Shack Authorized Service Facility, or transportation costs. Radio Shack is not responsible or liable for indirect, special, or consequential damages arising out of or in connection with the use or performance of the product or other damages with respect to loss of property, loss of revenue or profit, or costs of removal, installation or reinstallation.

EXCEPT AS PROVIDED HEREIN, RADIO SHACK MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. Some states do not allow the limitation or exclusion of incidental or consequential damages and some states do not allow limitation or exclusion of implied warranties; therefore, the aforesaid limitation(s) or exclusion(s) may not apply to the purchaser.

There will be charges rendered for repairs to the product made after the expiration of the aforesaid one (1) year warranty period.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

*We Service What We Sell* *9/94*

**Radio Shack**
**A Division of Tandy Corporation**
**Fort Worth, Texas 76102**
7A5 Printed in Hong Kong

Radio Shack®

# Dover Fashion Fone

## with 3 One-Touch and 10 Speed-Dial Memories

- **Memory Dialing**
- **Privacy**
- **Flash**
- **Redial**
- **Ringer Switch**
- **Tone or Pulse (Rotary) Dialing**
- **Hearing-Aid Compatible**

**Owner's Manual**

**Cat. No. 43-859**

# SET UP

To back up your phone's memories, install two AAA alkaline batteries (such as Radio Shack Cat. No. 23-555) into the battery compartment as indicated by the polarity markings (+ and –).

Plug the handset cord into the jacks on the handset and base.

Plug one end of the supplied telephone cord into the jack on the bottom of the phone. Plug the other end into a modular phone jack.

**Note:** The phone company can charge you for the installation of the necessary jacks. The USOC number of the jack to be installed is RJ11C.

**CAUTION**

RISK OF ELECTRIC SHOCK
DO NOT OPEN

This symbol is intended to alert you that parts inside the telephone present a risk of electric shock. Do not open the case

This symbol is intended to alert you to important operating and servicing instructions included in the papers with the telephone.

# USING THE PHONE

Turn the ringer on or off. You can make calls with the ringer off, and you can receive calls with the ringer off, if you hear another phone on the same line ring or see the LED light.

Switch to **T** (Tone) or **P** (Pulse) to match the type of service you have. If you have pulse (rotary) service, you can switch to **T** during a call to use tone services.

Press **MEMORY** once before you enter the location number for the phone number you want to store or dial. See "Storing/Dialing Numbers in Memory."

Press to disconnect a call.

Press **REDIAL** to dial the last number dialed (up to 31 tone or 32 pulse digits).

Press **FLASH** instead of the switchhook for special services such as call waiting.

Press **STORE** once to enter the telephone number you want to store. See "Storing/Dialing Numbers in Memory."

The LED lights when the phone rings, even when the ringer is off.

Press and hold **PRIVACY** to switch off the microphone during a call so you can listen to your caller without being heard.

## STORING/DIALING NUMBERS IN MEMORY

To store a number into memory:

1. Lift the handset and press **STORE.**
2. Enter the telephone number you want to store, up to 15 digits in tone mode and 16 digits in pulse mode.
3. Enter the number (**P1**–**P3**) for the one-touch memory location, or press **MEMORY** once and enter the number (**0**–**9**) for the speed-dial memory location where you want to store the phone number.
4. Repeat Steps 1-3 to store additional numbers. Return the handset to the cradle when you finish storing numbers.

Use the handset's index sheet to record stored numbers.

To dial a number in memory:

1. Lift the handset.
2. Press the number for the one-touch memory location (**P1**-**P3**), or press **MEMORY** and **e**nter the speed-dial memory location number for the phone number you want to call.

**© 1995 Tandy Corporation.**
**All Rights Reserved.**
**Radio Shack is a registered trademark used by Tandy Corporation.**